

DDJ-SP1

Hardware Diagram for CDJ / XDJ Control



Group	No.	Name	Function	+Shift	
1, Deck					
	1	DECK 1 OR 3	SELECT DECK 1 OR 3		
	2	DECK 2 OR 4	SELECT DECK 2 OR 4		
	3	SYNC	SYNC ON / OFF	MASTER	
	4	SLIP	SLIP MODE ON / OFF	QUANTIZE ON / OFF	
	5	CENSOR	SLIP REVERSE		
	6	PARAMETER ◀	LOOP HALF		
	7	PARAMETER ▶	LOOP DOUBLE		
	8	AUTO LOOP	Turn	LOOP HALF OR DOUBLE	
			Press	4 BEAT AUTO LOOP, LOOP OFF	
	9	SHIFT	SHIFT		
2, Performance Pads					
	9	HOT CUE	Hot Cue Mode		
	10	ROLL	Loop Mode		
	11	SLICER	Beat Jump Mode		
	1	PERFORMANCE PAD 1	<i>mode</i>		
			<i>Hot Cue</i>	HOT CUE 1	HOT CUE 1 DELETE
			<i>Loop</i>	1/4 BEAT LOOP	
			<i>Slip Loop</i>	1/16 BEAT SLIP LOOP	
			<i>Beat Jump</i>	BEAT JUMP (REV 1)	BEAT JUMP (REV 16)
	2	PERFORMANCE PAD 2	<i>mode</i>		
			<i>Hot Cue</i>	HOT CUE 2	HOT CUE 2 DELETE
			<i>Loop</i>	1/2 BEAT LOOP	
			<i>Slip Loop</i>	1/8 BEAT SLIP LOOP	
			<i>Beat Jump</i>	BEAT JUMP (FWD 1)	BEAT JUMP (REV 16)
	3	PERFORMANCE PAD 3	<i>mode</i>		
			<i>Hot Cue</i>	HOT CUE 3	HOT CUE 3 DELETE
			<i>Loop</i>	1 BEAT LOOP	
			<i>Slip Loop</i>	1/4 BEAT SLIP LOOP	

		<i>Beat Jump</i>	BEAT JUMP (REV 2)	
		<i>mode</i>		
4	PERFORMANCE PAD 4	<i>Hot Cue</i>	HOT CUE 4	HOT CUE 4 DELETE
		<i>Loop</i>	2 BEAT LOOP	
		<i>Slip Loop</i>	1/2 BEAT SLIP LOOP	
		<i>Beat Jump</i>	BEAT JUMP (FWD 2)	
		<i>mode</i>		
5	PERFORMANCE PAD 5	<i>Hot Cue</i>	HOT CUE 5	HOT CUE 5 DELETE
		<i>Loop</i>	4 BEAT LOOP	
		<i>Slip Loop</i>	1 BEAT SLIP LOOP	
		<i>Beat Jump</i>	BEAT JUMP (REV 4)	
		<i>mode</i>		
6	PERFORMANCE PAD 6	<i>Hot Cue</i>	HOT CUE 6	HOT CUE 6 DELETE
		<i>Loop</i>	8 BEAT LOOP	
		<i>Slip Loop</i>	2 BEAT SLIP LOOP	
		<i>Beat Jump</i>	BEAT JUMP (FWD 4)	
		<i>mode</i>		
7	PERFORMANCE PAD 7	<i>Hot Cue</i>	HOT CUE 7	HOT CUE 7 DELETE
		<i>Loop</i>	16 BEAT LOOP	
		<i>Slip Loop</i>	1/3 BEAT SLIP LOOP	
		<i>Beat Jump</i>	BEAT JUMP (REV 8)	
		<i>mode</i>		
8	PERFORMANCE PAD 8	<i>Hot Cue</i>	HOT CUE 8	HOT CUE 8 DELETE
		<i>Loop</i>	32 BEAT LOOP	
		<i>Slip Loop</i>	3/4 BEAT SLIP LOOP	
		<i>Beat Jump</i>	BEAT JUMP (FWD 8)	